

555-9001-316

Meridian IVR

VT100 Gateway Development Guide

Product release 2.0/1 Standard 1.0 February 1996

NORTEL
NORTHERN TELECOM

Meridian IVR

VT100 Gateway Development Guide

Publication number: 555-9001-316
Product release: Meridian IVR 2.0/I
Document release: Standard 1.0
Date: February 1996

© 1996 Northern Telecom
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Nortel, Meridian IVR, Meridian Mail, ACCESS, and Meridian 1 are trademarks of Northern Telecom. VT100, DEC, and VT420 are trademarks of Digital Equipment Corporation. HP, LaserJet, and ThinkJet are trademarks of Hewlett-Packard Company. X Window System and X are trademarks of the Massachusetts Institute of Technology. NCD is a trademark of Network Computing Devices Inc. UNIX is a registered trademark of AT&T. Voicetek and VTK are trademarks of Voicetek Corporation. Motif is a trademark of Open Software Foundation Inc. Touch tone is a trademark of Bell Canada. Intel and Pentium are trademarks of Intel Corporation. SCO is a trademark of The Santa Cruz Operation Inc.

Publication history

February 1996

This document is the first standard issue for Meridian IVR release 2.0/I.

Contents

About this guide ix

Who should use this guide.	ix
How to use this guide.	ix
Additional Nortel manuals	x
Conventions used in this guide	x

Chapter 1: About the VT100 Gateway 1-1

The VT100 terminal	1-1
The VT100 Gateway software	1-4

Chapter 2: Template files 2-1

Determining the required transactions.	2-1
Action templates	2-5
Action template syntax	2-6
Screen templates.	2-13
Initial-action templates	2-26

Chapter 3: Getting started 3-1

Before using the VT100 Gateway	3-1
screen.conf file.	3-2
Setting up the trs.conf file	3-4
Setting up the vt100.ctl file.	3-8
Setting up the com.conf file	3-10
A complete sample transaction	3-13
Initial-action template.	3-13
Action template performing a transaction	3-17

Chapter 4: IVR 2.0/I call flow interface **4-1**

Using the COMI, COMO, and COMA cells to access the host computer	4-1
Setting the COMI cell parameters	4-2
An application using the COMI, COMO, and COMA cells . . .	4-11

Appendix A: Host error messages **A-1**

Terminal Resource Server (TRS) Messages	A-1
---	-----

Glossary **Glossary-1**

List of figures

Figure 1-1	Terminals connected to a host computer	1-2
Figure 1-2	VT100 application screen sample	1-3
Figure 1-3	Meridian IVR 2.0/I VT100 Gateway configuration ...	1-4
Figure 1-4	TRS communication process	1-5
Figure 2-1	Voice response system vs. terminal operator	2-3
Figure 2-2	Action and screen templates	2-4
Figure 2-3	Action template syntax	2-6
Figure 2-4	Action template for accounting application	2-7
Figure 2-5	Reset-action template sequence sample	2-9
Figure 2-6	Reset-action template sample	2-10
Figure 2-7	Logout action flow	2-11
Figure 2-8	Logout-action template sample	2-12
Figure 2-9	Screen showing fields and the system prompt	2-14
Figure 2-10	Application screen for accounting application	2-15
Figure 2-11	Screen template syntax	2-16
Figure 2-12	Screen template for accounting application	2-17
Figure 2-13	The field-descriptor syntax	2-20
Figure 2-14	Key-descriptor line syntax	2-23
Figure 2-15	Sleep-descriptor syntax	2-25
Figure 3-1	screen.conf file syntax	3-3
Figure 3-2	screen.conf file	3-4
Figure 3-3	trs.conf file syntax	3-5
Figure 3-4	Initial-action template	3-6
Figure 3-5	trs.conf file for accounting application	3-8
Figure 3-6	vt100.ctl file syntax	3-9
Figure 3-7	vt100.ctl file for accounting application	3-9
Figure 3-8	com.conf file	3-11
Figure 3-9	Initial-action template for accounting application ..	3-14

Figure 3-10	Logout-action template used by the initial-action template for accounting application.....	3-16
Figure 3-11	Action template for accounting application.....	3-18
Figure 3-12	Reset-action template for accounting application .	3-19
Figure 3-13	Logout-action template for accounting application	3-20
Figure 4-1	Accessing the mainframe	4-1
Figure 4-2	Activating the gateway from a COMI cell	4-2
Figure 4-3	COMI cell parameter window	4-3
Figure 4-4	COMO cell parameter window	4-7
Figure 4-5	COMO cell.....	4-9
Figure 4-6	COMA cell in the CLEANUP branch of a START cell.....	4-10
Figure 4-7	IVR 2.0/I application accessing the TRS process from the COMI, COMO cells	4-12
Figure 4-8	COMI/COMO cell parameters, TRS templates, and VT100 screens	4-15

List of tables

Table 2-1	Valid field I/O entries	2-22
Table 2-2	Valid key names.....	2-24
Table 3-1	TRS default communication settings.....	3-10
Table 4-1	Branches of the COMO cell	4-9
Table 4-2	Application cell functions.....	4-13

List of procedures

Procedure 2-1	Accessing transaction information	2-5
---------------	---	-----